

KICKSTART INSTALLATION INSTRUCTIONS

Disconnect the 20 pin power supply connector from the computer motherboard and re-connect to one end of the Kickstart harness. Connect the other end of the harness into the motherboard.

Follow the twisted pair of wires from the front panel power button - usually orange and white - and disconnect from the motherboard.

Connect the two wire harness from the Kickstart kit back on to the two power pins on the motherboard. No polarity. That connector is usually identified as either PWR or P-ON on the board.

Stick the Kickstart PCB to the inside of the computer and you are done.